



motorola



User's Guide

Digital Audio Baby Monitor

Models: MBP140, MBP140-2

The features described in this User's Guide are subject to modifications without prior notice.

Welcome...

to your new Motorola Digital Audio Baby Monitor!

Thank you for purchasing the MBP140/MBP140-2. Now you can monitor the sound of your baby from another room.

Please retain your original dated sales receipt for your records.

For warranty service of your Motorola product, you will need to provide a copy of your dated sales receipt to confirm warranty status. Registration is not required for warranty coverage.

For product-related questions, please call:

+491805 938 802 in Europe

Email: motorola-mbp@tdm.de

On the Web: www.motorolahome.com/help

This User's Guide provides you with all the information you need to get the most from your product.


Before you use the baby monitor, we recommend you insert and fully charge the battery in the parent unit, so that it continues to work if you disconnect it from the mains power to carry it to another location. Please read the Safety Instructions on page 6 before you install the units.

Got everything?

- 1 x Parent unit with battery door
- 1 x Baby unit
- 1 x Charger Cradle with adaptor
- 1 x AAAx2 Ni-MH battery pack
- 1 x Lanyard
- 1 x Quick Start Guide

In packs with dual parent units, you will find an additional parent unit with charger cradle, power adaptor and rechargeable NiMH battery pack.

Overview of the Baby Unit



1. Nightlight Output

- On when the nightlight is turned on.
- Off when the nightlight is turned off.

2. Speaker

- To hear from Parent Unit when Talk is pressed.

3. Power indicator

- On when the baby unit is turned on.
- Off when the baby unit is turned off.

4. Control key panel

Nightlight ON/OFF button

- Press to turn on/off the nightlight.

Power ON/OFF button

- Press and hold to turn the baby unit on or off.


Volume - / +

- Press to adjust the speaker volume.

5. Microphone

6. Power adaptor

Overview of the Parent Unit



- 1. Power ON/OFF button** 
 - Press and hold to turn the parent unit on or off.
- 2. Volume** 
 - Press to decrease the speaker volume.
- 3. Power/link indicator**
 - On in green when the parent unit is powered on and linked to the baby unit.
 - On in orange when the parent unit battery is charging while linked to the baby unit.
 - Alternates in orange and red when the parent unit battery is charging while not linked to the baby unit.
 - Alternates in orange and green when the battery is low while linked to the baby unit.
- 4. Microphone**
 - Transmits sound to the baby unit speaker when Talk is pressed.
- 5. Volume** 
 - Press to increase the speaker volume.
- 6. Talk**
 - Press and hold to talk and comfort the baby.
- 7. Speaker**
- 8. Belt clip**
- 9. Battery compartment cover**
 - Flashes in orange when the battery is low while not linked to the baby unit.
 - Off when the parent unit is powered off.

Important guidelines for installing your Baby Monitor

- To use your baby unit and parent unit together, you must be able to establish a radio link between them, and the range will be affected by environmental conditions.
- Any large metal object, like a refrigerator, a mirror, a filing cabinet, metallic doors or reinforced concrete, between the baby and parent unit may block the radio signal.
- The signal strength may also be reduced by other solid structures, like walls, or by radio or electrical equipment, such as TVs, computers, cordless or mobile phones, fluorescent lights or dimmer switches.
- Use of other wireless products, such as wireless networks, Bluetooth™ systems or microwave ovens may cause interference with this product, so keep the baby monitor away from these types of products, or turn them off if they appear to be causing interference.
- If the signal is poor, try moving the parent and/or the baby unit to different positions in the rooms.
- It is recommended to place the baby unit about 1.5m from the Cot to ensure sound can be received and heard.
- It is essential to ensure sufficient clear space around the baby unit.



Table of contents

1. Safety Instructions	7
2. Getting Started	9
2.1 Connecting baby unit to power	9
2.2 Installing battery and connecting parent unit to power	9
2.3 Installation of Lanyard	10
3. Using Your Baby Monitor	12
3.1 Power on or off the baby unit	12
3.2 Power on or off the parent unit	12
3.3 Set nightlight	12
3.4 Adjust the speaker volume for parent unit	12
3.5 Adjust the speaker volume for baby unit	13
3.6 Talk back to the baby unit	13
4. Disposal of The Device (environment)	14
5. Cleaning	15
6. Troubleshooting	16
7. General Information	17



1. Safety Instructions



Presence of un-insulated dangerous voltage within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



WARNING:

Presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

This Baby Monitor is compliant with all relevant standards regarding electromagnetic fields and is, when handled as described in the User's Guide, safe to use. Therefore, always read the instructions in this User's Guide carefully before using the device.

- Use mains power sockets that are near the equipment and easily accessible.
- Determine a location for the baby monitor that will provide the best audio reception of your baby in his cot.
- NEVER place the baby monitor within the cot.
- Adult assembly is required. Keep small parts away from children when assembling.
- This product is not a toy. Do not allow children to play with it.
- This baby monitor is not a substitute for responsible adult supervision.
- Keep this User's Guide for future reference.
- Do not cover the baby monitor with a towel or blanket.
- Test this monitor and all its functions so that you are familiar with it prior to actual use.
- Do not use the baby monitor near water.
- Do not install the baby monitor near a heat source.

CAUTION


In order to reduce the risk of fire or electrical shock, do not expose the device to water or humidity. Never disassemble the device. Opening the casing is dangerous and will invalidate the warranty.

The electrical plug is used to disconnect the device and it should remain readily operable during use. In order to disconnect the apparatus from power completely, the socket plug should be disconnected from the electrical socket completely.

You chance the risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to their instructions. Use only the provided rechargeable battery pack.

2. Getting Started

2.1 Connecting baby unit to power




- Choose a suitable location with easy access to a mains power socket.
- Plug the baby unit into the power socket in your baby's room. Ensure sufficient clearance is given for it to detect sound and place it not more than 1.5m away from the baby's cot.


2.2 Installing battery and connecting parent unit to power

A rechargeable battery pack is supplied and should be fitted, so that the parent unit can be moved without losing the link from the baby unit(s). Charge the parent unit before you use it for the first time or when the parent unit indicates that the battery is low.


- Slide off the battery compartment cover.
- Insert the plug of the battery pack into the jack inside the battery compartment, and fit the battery pack into the compartment.



- C. Slide the battery compartment cover back until it securely clicks into place.



- D. Place the parent unit onto the charger. Connect the power adaptor of the charger to a suitable power socket.




NOTE

Only use the provided battery pack.


2.3 Installation of Lanyard

A lanyard is supplied as an additional wearable option for the parent unit other than the belt clip. Follow the steps below for installing the lanyard:


- Open the battery door of the parent unit.
- Hook the string loops of the lanyard over the plastic catches inside the battery compartment as shown in the diagram.



- C. Make sure the 2 string loops sit properly over the 2 plastic catches.




- D. Close the battery door.




- E. Open/Close the Lanyard Lock.

- Pull with force to open the lock.



- Push to close the lock.



3. Using Your Baby Monitor

Please read these instructions carefully, and be aware that this baby monitor is only intended as an aid. It is not a substitute for responsible, correct parental supervision.

3.1 Power on or off the baby unit

- Press and hold  to turn on the baby unit. The Power indicator turns on.
- Press and hold  again to turn off the baby unit. The Power indicator light turns off.

3.2 Power on or off the parent unit

- Press and hold  to turn on the parent unit. The Power/link indicator turns on.
- Press and hold  again to turn off the parent unit. The Power/link indicator turns off.

NOTE

Do not place the parent and baby units too close together or you may hear a high pitched noise. This is audio feedback, not a defect in the unit. The units are designed to be operated at some distance apart, e.g. in separate rooms.

3.3 Set nightlight

The nightlight feature is for giving the room a soft glow so the baby can be observed without disrupting it with bright lights.

- When the nightlight is off, press  on the baby unit to turn it on.
- When the nightlight is on, press  on the baby unit to turn it off.

3.4 Adjust the speaker volume for parent unit

You can adjust the speaker volume from Volume 1 to Volume 5.

- Press  or  on the parent unit when it is not in use.

NOTE

If no sound is detected from the baby unit for about 15 seconds, the speaker on the parent unit will go into standby mode and turn off. Any sound will immediately turn it back on.



3.5 Adjust the speaker volume for baby unit

You can adjust the speaker volume from Volume 1 to Volume 5, to increase or decrease the sound heard by the baby from a parent unit when its Talk  button is pressed.

- Press  or  on the baby unit.

3.6 Talk back to the baby unit

- Press and hold the Talk  button on the parent unit to be able to talk back to your baby.

4. Disposal of The Device (environment)

At the end of the product lifecycle, you should not dispose of this product with normal household waste. Take this product to a collection point for the recycling of electrical and electronic equipment. The symbol on the product, User's Guide and/or box indicates this.



Some of the product materials can be re-used if you take them to a recycling point. By reusing some parts or raw materials from used products you make an important contribution to the protection of the environment.

Please contact your local authorities in case you need more information on the collection points in your area.

Dispose of the battery pack in an environmentally-friendly manner according to your local regulations.

5. Cleaning

Clean your Baby Monitor with a slightly damp cloth or with an anti-static cloth. Never use cleaning agents or abrasive solvents.

Cleaning and care

- Do not clean any part of the Baby Monitor with thinners or other solvents and chemicals – this may cause permanent damage to the product which is not covered by the warranty.
- Keep your Baby Monitor away from hot, humid areas or strong sunlight, and do not let it get wet.
- Every effort has been made to ensure high standards of reliability for your Baby Monitor. However, if something does go wrong, please do not try to repair it yourself – contact Customer Service for assistance.

IMPORTANT

Always switch off and disconnect the power adaptor before cleaning your baby monitor.

6. Troubleshooting

Power/link Indicator on the parent unit does not come on

- The baby unit may be switched off. Press the  button to switch on the baby unit.
- Check whether the supplied battery pack is correctly installed and that it is not drained.
- Recharge the parent unit by placing it in a charger cradle connected to the mains.

Power Indicator on the baby unit flashes

- The baby unit may be switched off. Press the  button to switch on the baby unit.
- The parent unit and the baby unit may be out of range with each other. Reduce the distance between the units, but not closer than 1.5m.

The parent unit beeps

- The parent unit may have lost connection with the monitoring baby unit. Reduce the distance between the parent unit and the baby unit, but not closer than 1.5m.
- The baby unit may be switched off. Press the  button to switch on the baby unit.
- Battery pack in parent unit is running low. Place the parent unit in a charger cradle connected to mains power for recharging.

Cannot hear sound or baby cry from the parent unit

- The volume level in the parent unit may be set too low. Increase the volume level of the parent unit. Refer to section 3.4 for volume level settings
- The parent unit and the monitoring baby unit may be out of range with each other. Reduce the distance between the units, but not closer than 1.5m.

The baby monitor system produces a high-pitched noise

- The parent unit and the baby unit are too close to each other. Make sure the parent unit and baby unit are at least 1.5m away from each other.
- The speaker volume of the parent unit maybe set too high. Decrease the volume of the parent unit.

Battery pack in the parent unit is running low quickly

- The volume level of the parent unit may be set too high which consumes power. Decrease the volume level of the parent unit. Refer to section 3.4 for volume level settings.

7. General Information

If your product is not working properly....

1. Read this User's Guide.
2. Contact Customer Service at
+491805 938 802 in Europe
Email: motorola-mbp@tdm.de
On the Web: www.motorolahome.com/help

To order a replacement battery pack for parent unit, contact customer service.

Consumer Products and Accessories Limited Warranty ("Warranty")

Thank you for purchasing this Motorola branded product manufactured under license by Binatone Electronics International LTD ("BINATONE")

What Does this Warranty Cover?

Subject to the exclusions contained below, BINATONE warrants that this Motorola branded product ("Product") or certified accessory ("Accessory") sold for use with this product that it manufactured to be free from defects in materials and workmanship under normal consumer usage for the period outlined below. This Warranty is your exclusive warranty and is not transferable.

THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY HAVE OTHER RIGHTS THAT VARY BY STATE, PROVINCE OR COUNTRY. FOR CONSUMERS WHO ARE COVERED BY CONSUMER PROTECTION LAWS OR REGULATIONS IN THEIR COUNTRY OF PURCHASE OR, IF DIFFERENT, THEIR COUNTRY OF RESIDENCE, THE BENEFITS CONFERRED BY THIS LIMITED WARRANTY ARE IN ADDITION TO ALL RIGHTS AND REMEDIES CONVEYED BY SUCH CONSUMER PROTECTION LAWS AND REGULATIONS. FOR A FULL UNDERSTANDING OF YOUR RIGHTS YOU SHOULD CONSULT THE LAWS OF YOUR COUNTRY, PROVINCE OR STATE.

Who is covered?

This Warranty extends only to the first consumer purchaser, and is not transferable.

What will BINATONE do?

BINATONE or its authorised distributor at its option and within a commercially reasonable time, will at no charge repair or replace any Products or Accessories that do not conform to this Warranty. We may use functionally equivalent reconditioned/ refurbished/ pre-owned or new Products, Accessories or parts.

What Other Limitations Are There?

ANY IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED TO THE DURATION OF THIS LIMITED WARRANTY, OTHERWISE THE REPAIR OR REPLACEMENT PROVIDED UNDER THIS EXPRESS LIMITED WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER, AND IS PROVIDED IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED. IN NO EVENT SHALL MOTOROLA OR BINATONE BE LIABLE, WHETHER IN CONTRACT OR TORT (INCLUDING NEGLIGENCE) FOR DAMAGES IN EXCESS OF THE PURCHASE PRICE OF THE PRODUCT OR ACCESSORY, OR FOR ANY INDIRECT, INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES OF ANY KIND, OR LOSS OF REVENUE OR PROFITS, LOSS OF BUSINESS, LOSS OF INFORMATION OR OTHER FINANCIAL LOSS ARISING OUT OF OR IN CONNECTION WITH THE ABILITY OR INABILITY TO USE THE PRODUCTS OR ACCESSORIES TO THE FULL EXTENT THESE DAMAGES MAY BE DISCLAIMED BY LAW.

Some jurisdictions do not allow the limitation or exclusion of incidental or consequential damages, or limitation on the length of an implied warranty, so the above limitations or exclusions may not apply to you. This Warranty gives you specific legal rights, and you may also have other rights that vary from one jurisdiction to another.

Products Covered	Length of Coverage
Consumer Products	Two (2) years from the date of the products original purchase by the first consumer purchaser of the product.
Consumer Accessories	Ninety (90) days from the date of the accessories original purchase by the first consumer purchaser of the product.
Consumer Products and Accessories that are Repaired or Replaced	The balance of the original warranty or for Ninety (90) days from the date returned to the consumer, whichever is longer.

Exclusions

Normal Wear and Tear. Periodic maintenance, repair and replacement of parts due to normal wear and tear are excluded from coverage.

Batteries. Only batteries whose fully charged capacity falls below 80% of their rated capacity and batteries that leak are covered by this Warranty.

Abuse & Misuse. Defects or damage that result from: (a) improper operation, storage, misuse or abuse, accident or neglect, such as physical damage (cracks, scratches, etc.) to the surface of the product resulting from misuse; (b) contact with liquid, water, rain, extreme humidity or heavy perspiration, sand, dirt or the like, extreme heat, or food; (c) use of the Products or Accessories for commercial purposes or subjecting the Product or Accessory to abnormal usage or conditions; or (d) other acts which are not the fault of MOTOROLA or BINATONE., are excluded from coverage.

Use of Non-Motorola branded Products and Accessories. Defects or damage that result from the use of Non-Motorola branded or certified Products or Accessories or other peripheral equipment are excluded from coverage.

Unauthorised Service or Modification. Defects or damages resulting from service, testing, adjustment, installation, maintenance, alteration, or modification in any way by someone other than MOTOROLA, BINATONE or its authorised service centres, are excluded from coverage.

Altered Products. Products or Accessories with (a) serial numbers or date tags that have been removed, altered or obliterated; (b) broken seals or seals that show evidence of tampering; (c) mismatched board serial numbers; or (d) nonconforming or non-Motorola branded housings, or parts, are excluded from coverage.

Communication Services. Defects, damages, or the failure of Products or Accessories due to any communication service or signal you may subscribe to or use with the Products or Accessories is excluded from coverage.

How to Obtain Warranty Service or Other Information?

To obtain service or information, please call:

+491805 938 802 in Europe

Email: motorola-mpb@tdm.de

On the Web: www.motorolahome.com/help

You will receive instructions on how to ship the Products or Accessories at your expense and risk, to a BINATONE Authorised Repair Centre.

To obtain service, you must include: (a) the Product or Accessory; (b) the original proof of purchase (receipt) which includes the date, place and seller of the Product; (c) if a warranty card was included in your box, a completed warranty card showing the serial number of the Product; (d) a written description of the problem; and, most importantly; (e) your address and telephone number.

These terms and conditions constitute the complete warranty agreement between you and BINATONE regarding the Products or Accessories purchased by you, and supersede any prior agreement or representations, including representations made in any literature publications or promotional materials issued by BINATONE or representations made by any agent employee or staff of BINATONE, that may have been made in connection with the said purchase.



BINATONE TELECOM PLC

1 Apsley Way London NW2 7HF, United Kingdom.
Tel: +44(0) 20 8955 2700 Fax: +44(0) 20 8344 8877
e-mail: binatoneuk@binatone telecom.co.uk



EC Declaration of Conformity

We the manufacturer / Importer : Binatone Telecom Plc
1 Apsley Way London
NW2 7HF, United Kingdom.

Declare under our sole responsibility that the following product
Type of equipment: Digital Audio Baby Monitor
Model Name: MBP140, MBP140-2
Country of Origin: China
Brand: Motorola

complies with the essential protection requirements of R&TTE Directive 1999/5/EC on the approximation of the laws of the Member States relating to **Radio Spectrum Matters**, the Council Directive 2004/108/EC on the approximation of the laws of the Member States relating to **electromagnetic compatibility (EMC)** and the European Community Directive 2006/95/EC relating to **Electrical Safety**, Directive 2011/65/EC on the restriction of use of hazardous substances (RoHS) and 2009/125/EC relating to ecodesign requirement for Energy-Related Products (ErP).

Assessment of compliance of the product with the requirements relating to the essential requirements according to Article 3 R&TTE was based on Annex III of the Directive 1999/5/EC and the following standard:

Radio Spectrum:	EN 301406 v2.1.1 (2009-07)
EMC:	EN 301489-6 v1.4.1
	EN 301489-1 v1.9.2 (2011-09)
RF Safety:	EN 62479: 2010 (For Baby Unit)
	EN 50385: 2002 (For Parent Unit)
LED measurement:	EN 62471: 2008
Electrical Safety:	EN 60950-1: 2006+A11: 2009+A1: 2010+A12:2011+A2: 2013

The product is labelled with the European Approval Marking CE as show. Any Unauthorised modification of the product voids this Declaration.



Manufacturer / Importer
(Signature of authorised person)

Karl Heinz Mueller / Chief Technical Officer

London, 16 Jun 2016

Place & Date

Technical Specifications

Baby unit

Frequency	1881.792 MHz - 1897.344 MHz
Channels	10
Operating temperature	5°C - 45°C
Power supply adaptor	Input 100-240VAC, 50/60Hz.
Rating	Output 6VDC, 450mA.

Parent unit

Frequency	1881.792 MHz - 1897.344 MHz
Channels	10
Operating temperature	5°C - 45°C
Battery rating	2.4V, 400mAh Ni-MH battery pack
Power supply adaptor	Input 100-240VAC, 60Hz.
Rating	Output 6VDC, 400mA.

Specifications are subject to change without prior notice.



Manufactured, distributed or sold by Binatone Electronics International LTD., official licensee for this product. MOTOROLA and the Stylized M Logo are trademarks or registered trademarks of Motorola Trademark Holdings, LLC, and are used under license. All other trademarks are the property of their respective owners. © 2016 Motorola Mobility LLC. All rights reserved.



EN_EU Version 4.0

Printed in China